



i5770™ Camera

Pan, Tilt and Zoom

The i5770 Camera with IR remote control is a compact, easy-to-use, high quality color camera with the flexibility of remote 360° pan/tilt/zoom operation.

- Among the widest movement ranges available for views from nearly anywhere in a room.
- The 18x optical zoom makes it ideal for tight hospital areas that are difficult to maneuver about.
- Ability to capture video in low light areas expands its versatility in hospitals and other medical facilities.

The Shot You Want

In addition to wide ranging pan, tilt and zoom, the i5770 can be mounted upside down if necessary, and it will automatically flip images for proper display orientation. The camera can even shoot diagonally.

- Zoom lens includes auto and manual focus to suit user preference.
- 64 custom preset function provides maximum amount of control of the shot.
- Fully remote controllable via RS232C (VISCA) and supported software.

The Solution You Need

The i5770 works with all popular video conferencing software, including EasyShare®VC, Polycom®, TANDBERG, Vidyo, Adobe Connect, Skype and others on your PC.

- Easy to install.
- Can be ceiling mounted or used on a desktop.
- Small and lightweight.



Works with your PC or Mac and on most popular video codecs including:





Specifications

Signal System	NTSC or PAL
Image Sensor	1/4-type Sony CCD
Number of Effective Pixels	768 x 494 (NTSC); 752 x 582 (PAL)
Horizontal Resolution	480 TV Lines (wide end)
Lens	18x Optical zoom, 2x Digital zoom f = 4.1 mm (wide) to 73.8 mm (tele), F1.4 to F3.0
Video Output	RCA (S-Video Converter available)
Minimum Illumination	1.0 Lux
Auto Exposure	Auto/Manual/Priority AE, Exposure and Back-light compensation
Pan/Tilt Pan	±300° (Max. speed: 70°/s) Tilt: -30° to +90° (Max, speed: 50°/s)
Position Preset	64 Positions
Power Consumption	<10W
Dimensions (W x H x D)	137 x 140 x 156 mm 53.94 x 55.12 x 61.41 in.
Weight	Approximately 2 lb 3 oz (1Kg)
Supplied Accessories	AC Adapter IR Remote Control Unit Operating Instructions
Mounting Options	Ceiling Mount or Desktop Installation
Body Color	Black

Works with your PC or Mac and on most popular video codecs including:

